

MICROMEMO

High-fidelity digital audio recorder for iPod

Setup and Recording

1. Attach MicroMemo to the bottom of your iPod with video. This will automatically switch the iPod into **Voice Memos** mode. Once in memos mode, all recording and playback is controlled using the **iPod's Click Wheel**.
2. To start recording, select **Record**. During recording, the on-screen timer will display the length of your recording.
3. To pause recording, select **Pause**.
4. To continue recording, select **Continue**.
5. To stop recording, select **Stop and Save**. MicroMemo will end the recording and name it with the current date and time.

Playback

1. Recordings are automatically stored under **extra >Voice Memos** in your iPod.
 2. To play a recording, scroll to the file you want and select **Play**.
- Playback can be heard through either the headphone jack or through MicroMemo's built-in speakers.

Delete Recordings

To delete a memo, scroll to it in the list of **Voice Memos** and select **Delete Memo**.