

SNOWBALL USB MICROPHONE

You will need an editing and recording program. **Audacity** is a free editing and recording software. **You can get the free audacity download on the internet.** Use your snowball microphone for high quality recording.

Windows Setup Procedure:

- 1.** In Windows XP Home Edition or XP Professional: Click **START**.
- 2.** Click on **CONTROL PANEL**
- 3.** Click on **SOUNDS, SPEECH AND AUDIO DEVICES**.
- 4.** Click on **SOUNDS AND AUDIO DEVICES**.
- 5.** Select the **AUDIO** tab. Under **SOUND RECORDING** insure that the **BLUE BALL USB MIC** is selected as the **DEFAULT DEVICE**.
- 6.** Click on **VOLUME**; select appropriate volume level. The microphone is sensitive and may require a very low volume setting.
- 7.** Click **OK**.
- 8.** Exit control panel.

Macintosh Setup Procedure:

- 1.** In system OSX: in the Apple menu, open **SYSTEM PREFERENCES**.
- 2.** Double click the **SOUND** preference file.
- 3.** Click on the **INPUT** tab.
- 4.** Double click **BLUE USB BALL MIC** under **CHOOSE A DEVICE FOR SOUND INPUT** dialog box.
- 5.** Set input volume to the appropriate level. The microphone is sensitive and may require a very low volume setting.
- 6.** Exit **SYSTEM PREFERENCES**.